## **BNC** Series TEE ADAPTOR






#### PLUG TO PLUG TO PLUG "T" ADAPTOR

P/N	Cable Group	Impedance
111-T010	N/A	50






#### PLUG TO JACK TO PLUG "T" ADAPTOR

P/N	Cable Group	Impedance
111-T020	N/A	50






### JACK TO JACK TO PLUG "T" ADAPTOR

P/N	Cable Group	Impedance
111-T030	N/A	50





### JACK TO PLUG TO JACK "T" ADAPTOR

P/N	Cable Group	Impedance
111-T041	N/A	50

### E C

# **BNC** Series TEE ADAPTOR






### JACK TO JACK TO JACK "T" ADAPTOR

P/N	Cable Group	Impedance
111-T051	N/A	50

### **BNC** Series


### **TEE ADAPTOR**





# PLUG TO DOUBLE JACK P/N Cable Group Impedance 111-T040 N/A 50





THREE JACK		
P/N	Cable Group	Impedance
111-T052	N/A	50